Ⓐ

# ASSEMBLY INSTRUCTION

**SKU# 512-924**

**NOTE**: Please consult a qualified electrician if you are not certain of the installation.

**CAUTION** : Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

1. Pull the supply wires and house ground wires out from the outlet box and fasten the mounting strap onto outlet box using 2 outlet box screws.
2. Screw off ring from screw collar loop and thread the screw collar loop to the top nipple on the mounting strap. Place the ring and canopy over the chain on the fixture.
3. Fasten the top loop down to the nipple on the wall plate as shown.
4. Connect loop on the wall plate , bottom loop and loop on the support by using rods as shown.
5. Using two pliers ,twist open one link at the end of the chain. Hook it to the top loop and close the link .Weave the fixture wires and ground wires up through the chain links, through the ring and through canopy. Position both the outlet box supply wires and the fixture wires outside of the outlet box to facilitate connection. After connection is completed ,carefully position wires back inside outlet box. Using two pliers, twist one the link at the other end of the chain. Hook the whole fixture to the screw collar loop on the ceiling and close the link.
6. Connect the wire with writing on it from the fixture to the black wire from the supply circuit. Connect the wire without writing on it (with raised ribs) from the fixture to the white wire from the supply circuit. Cover the connections using the wire connectors provided .Tie the ground wires from outlet box and fixture to the ground wire screw on the mounting strap.
7. Place the canopy over the nipple all the way to the ceiling and tighten the ring onto screw collar loop until the canopy is firmly held against the ceiling.
8. Screw the bottom nipple to the bushing located at the bottom of the fixture. Secure the nipple by screwing the hex nut against the bushing.
9. Install the bulbs(bulbs included)
10. Place the ceiling pan, glass shade, rubber washer and lock washer over the bottom nipple & secure them using the nut until the glass hold firmly to the fixture. Place the bottom cap over the bottom nipple and secure it by tightening the finial.